# **Dash Cam Icon Reference**



#### 1 - Power

No light – no power connection Green light – normal power connection

### 2 - Alarm

No light – default Red light – blinks three times when a video event is triggered

## 3 - GPS

No light – normal GPS signal Red light – no GPS signal

### 4 - Network

No light – normal 4G cellular network connection Red light – no 4G cellular network connection

5 - Local Wi-Fi Signal (camera install) Used by camera installers.

No light - normal

Red light – if red light stays on, contact support

Copyright 2024 J. J. Keller & Associates, Inc.

# 00\$\$⊕??∆2⊡0

# 6 - Road-Facing Camera

No light – normal video recording Red light – road-facing camera not recording

### 7 - Driver-Facing Camera

Not applicable to road-facing only camera users **No light** – normal video recording **Red light** – driver-facing camera not recording

## 8 - Auxiliary Camera(s)

Applicable if auxiliary camera(s) are installed No light – auxiliary camera is working Red light – auxiliary camera not working

## 9 - Driver-Initiated Recording Button

Push to manually capture a 10-second video





www.JJKeller.com/Glovebox

73972